
# VELOSIT® RM 202

# Universal Vertical and Overhead Repair Mortar





#### Application fields

VELOSIT RM 202 is a cementitious repair mortar for all types of construction substrates. It creates a good surface for coatings and overlays. Typical application fields besides others are as follows:

- Repair of surface defects on concrete, masonry, many natural stones and steel
- Overlays and repairs on concrete structures like dams, bridges, beams, balconies, facades
- Application on horizontal and vertical incl. overhead areas
- Filling of blow holes, honeycombs and surface roughness
- Application thickness from feather-edge to 100 mm (4")
- Re-modeling of architectural features requiring a moldable mortar that can be shaved into shape

### **Properties**

VELOSIT RM 202 is a shrinkage compensated cementitious repair mortar with very quick strength development. VELOSIT RM 202 binds the mixing water very fast reducing or completely eliminating the need for water curing and protection. VELOSIT RM 202 creates an extremely well bonded, rigid abrasion resistant layer on the substrate.

VELOSIT RM 202 surpasses the requirements of EN 1504-3 class R3 for concrete repair (CR) and can be used according to the principles 3, 4 and 7 acc. to EN 1504-9.

VELOSIT RM 202 can be applied by trowel or suitable spray equipment.

- Minimal shrinkage/expansion under dry resp. wet curing conditions minimizing the risk of micro-cracking
- Excellent workability especially overhead
- · Fiber reinforced
- 40 min. working time and 15 MPa (2175 psi) compressive strength after 4 hours



2319 page 1 of 4



- Final strength of more than 50 MPa (7250 psi) after 28 days
- Open to foot traffic after 3 4 hours
- Very good adhesion to properly prepared concrete and masonry
- Water curing only under hot and dry conditions required for 3 – 4 hours
- Good resistance against CO<sub>2</sub> and Chloride penetration due to a very tight pore structure
- Good resistance against aggressive media with a pH range of 3-12 and against soft water with low ion content
- Good weathering resistance
- Good sulfate resistance
- Light gray color close to concrete color

#### **Application**

#### 1.) Substrate preparation

VELOSIT RM 202 is designed for mineralic substrates like concrete, masonry or absorptive natural stones. Steel may be coated with a suitable bonding bridge.

- a.) Steel must be prepared to a purity of SA 2.5 acc. SIS 05 5900. Apply a corrosion protection coat on rebar with VELOSIT CP 201. Other steel areas can be primed with VELOSIT PR 303 with a full broadcast. Steel may expand and contract differently under temperature changes than a cementitious mortar. Thus steel application is only recommended if steel is embedded in larger concrete bodies or the temperature is not subject to major changes.
- b.) Mineralic substrates (concrete, masonry, cement compatible natural stones) must be prepared with sand blasting, shot blasting or ideally high pressure water blasting (> 100 bar/1450 psi) to remove all bond breaking substances.

On reinforced concrete remove all carbonated concrete. Test with Phenolphthalein or other suitable indicator until concrete with sufficient alkalinity for rebar protection is reached. If rebar is exposed remove concrete at least 6 mm (1/4") behind rebar to fully embed the steel into

VELOSIT RM 202.

Substrate must be rough, open porous and load bearing. The minimum requirement for adhesive strength is 1.5 MPa (218 psi) and for the compressive strength 25 MPa (3625 psi). Lower strength values can be accepted if lower adhesive strength is acceptable. Active water leaks must be treated and fully stopped with VELOSIT PC 221. Leaking cracks need to be sealed with a PU injection material. Before the application of VELOSIT RM 202, dampen the substrate with clean water to a saturated surface dry (SSD) condition.

c.) Concrete repair acc. EN 1504-9 principle 3, 4 or 7 requires a prime coat with VELOSIT CP 201 on concrete and rebar surface to ensure best adhesion strength results.

#### 2.) Processing

Mixing: Mix VELOSIT PRM 202 with 15-18% potable water, i.e. 3.8-4.5 l (1.0-1.2 gal.) water per 25 kg (55 lb.) bag. Fill the 15 % mixing water (3.8 l per bag) into a suitable bucket and mix the powder with a slow speed drill (300-600 rpm) into the water until a lump-free mix is achieved. Add more water (max. 3 %) under stirring until the desired consistency is achieved.

The product is workable for 40 min. at 23 °C.

Priming: Apply a prime coat of VELOSIT RM 202 with a wet sponge to the pre-dampened substrate. Work approximately 0.5-1 kg per m<sup>2</sup> (1-2 lbs. per 10 ft<sup>2</sup>) into the surface pores.

If working acc. to EN 1504-9 the prime coat must be applied with VELOSIT CP 201!

#### a.) Trowel application:

Trowel VELOSIT RM 202 fresh in fresh into the prime coat. The product can be applied up to 100 mm (4") on vertical areas. Larger overhead areas may limit the thickness to max. 50 mm (2"). Make sure to work in sections that can be finished within 40 min. Rebars and other penetrations must be fully embedded into the mortar.



2319 page 2 of 4



b.) Spray application:

Use suitable spray machines such as:

- PFT GmbH: PFT G4

- HighTech GmbH: HighComb Big

- Wagner GmbH: PC 25

- Putzmeister GmbH: SP12 or MP 25

- Inotec GmbH: INOMAT-M8

In mixing pumps feed the powder into the product hopper and adjust the water to the desired

consistency.

With mortar pumps add the mixed product as described under "Mixing" into the feed hopper of the spray machine and spray continuously. If a smooth surface is required, follow with a trowel shortly after material is sprayed. Work in sections. Long spray interruptions may result in clogging of the spray hose. The product may cure a lot faster if the hose is exposed to direct sunlight. Always empty and flush the machine after spraying or before long spray interruptions. VELOSIT RM 202 is a fast curing material and may be hard to remove if left in the machine.

c.) Re-modeling of architectural features: Once VELOSIT RM 202 applied by trowel or spray machine has started to set it can be sculpted as needed. Shave off material in thin layers to achieve desired form. If needed finish surface with a slightly wet sponge to remove surface imperfections and air voids.

#### 3.) Curing

VELOSIT RM 202 does not require long term curing as it reacts relatively fast with water. Only under hot weather or very dry conditions water curing for 3 – 4 hours is required.

# **Estimating**

Repair of surface defects:

25 kg (55 lbs.) VELOSIT RM 202 result in approx. 15.6 liter (0.55 ft<sup>3</sup>) cured mortar.

**Surface Coating:** 

10 kg (22 lbs.)\* VELOSIT RM 202 per m<sup>2</sup> (10.7 ft<sup>2</sup>) for 6 mm (1/4") dry mortar thickness on smooth substrates. Depending on surface roughness application rates can be significantly higher.

\* 10 kg VELOSIT RM 202 powder + 1.7kg water, i.e. 11.7kg mixed material per 6 mm and m<sup>2</sup>

# **Cleaning**

VELOSIT RM 202 can be removed in the fresh state with water. Once it has cured acidic cleaners like muriatic acid and mechanical cleaning are required.

#### **Quality features**

Color: gray Mixing ratio by weight: 100:17 Mixing ratio by volume: 100:27 Density: 1.6 kg/l Substrate temperature: 5 - 35°C  $(40 - 95 ^{\circ}F)$ 

Initial set: 55 min. Final set. 120 min.

Compressive / flexural strength:

4 hours: 15 / 2 MPa (2175/290 psi) 24 hours: 31 / 5 MPa (4495/725 psi) 45 / 8 MPa (6525/1160 psi) 7 days: 28 days: 56 / 9 MPa (8120/1305 psi) Chloride ions: < 0.05 %

Carbonation resistance: passed

Capillary water absorption:  $0.1 \text{ kg/m}^2 \text{ x h}^{0.5}$ 

Adhesive strength\*:

- primed with RM 202: 1.8 MPa (261 psi) - primed with CP 201: 2.2 MPa (319 psi) Restrained shrinkage: 1.5 MPa (218 psi)

# **Packaging**

VELOSIT RM 202 is available in 25 kg (55 lb.) watertight plastic bags.



<sup>\*</sup>acc. EN 1542. Adhesion depends very much on proper surface preparation!



# **Storage**

VELOSIT RM 202 can be stored in unopened original packs for 12 months at 5-35 °C (40-95 °F) in a dry storage place protected against sunlight.

# Safety

Please observe the actual valid material safety data sheet and follow the described safety measures for handling of the product.

#### Recommendations

VELOSIT RM 202 is only available for professional applicators.

Never add water to VELOSIT RM 202 when it has started to set. Stiffened material must be disposed.

All described product features are determined under controlled laboratory conditions according to the relevant international standards. Values determined under job site conditions may deviate from the stated values.

Please always use the latest version of this data sheet available from our website www.velosit.de.

#### Manufacturer

VELOSIT GmbH & Co. KG Industriepark 7 32805 Horn-Bad Meinberg Germany

